

Part 91—General operating and flight rules

Table of contents

Subpart 91.A—Preliminary

- 91.005 Application of Part 91—Australian aircraft in Australian territory
- 91.010 Application of Part 91—Australian aircraft in foreign countries
- 91.015 Application of Part 91—Australian aircraft over the high seas
- 91.020 Application of Part 91—foreign registered aircraft
- 91.025 Application of Part 91—foreign state aircraft
- 91.030 Application of Part 91—aircraft to which Part 101, 103 or 131 applies
- 91.035 Application of Part 91—certain provisions of this Part do not apply if provisions of Part 105, 121, 133, 135 or 138 apply
- 91.040 Issue of Manual of Standards for Part 91
- 91.045 Approvals by CASA for Part 91
- 91.050 Approvals by authorised persons for Subpart 91.T

Subpart 91.C—General

Division 91.C.1—General flight limitations

- 91.055 Aircraft not to be operated in manner that creates a hazard
- 91.060 Unauthorised travel or placing of cargo on aircraft
- 91.085 NVIS flights
- 91.090 All flights—airspeed limits

Division 91.C.2—Operational documents

- 91.095 Compliance with flight manual etc.

Division 91.C.3—Flight related documents

- 91.100 Electronic documents
- 91.105 Carriage of documents
- 91.110 Carriage of documents for certain flights
- 91.115 Carriage of documents—flights that begin or end outside Australian territory
- 91.120 Journey logs—flights that begin or end outside Australian territory

Division 91.C.4—Reporting and recording defects and incidents etc.

Division 91.C.5—Search and rescue services and emergency and survival equipment

Division 91.C.6—Miscellaneous requirements for aircraft

- 91.140 Operating an Australian aircraft outside Australia
- 91.145 Requirements to be met before Australian aircraft may fly
- 91.150 Operating aircraft with inoperative equipment—placarding
- 91.155 Manipulating flight controls

Division 91.C.7—Firearms on aircraft

- 91.160 Possessing firearm on aircraft